


# Zep System II

## Quick Start Guide v3.0




This guide is intended to provide a quick introduction to the Zep System II standard installation procedure. It is not intended to replace the full Installation Manual.

**IMPORTANT:** Read the *Zep System II PV Module Installation Manual*, in its entirety, prior to installing your first Zep System II PV array. The installation manual can be found at: [www.zepsolar.com/resources.html](http://www.zepsolar.com/resources.html), where you will also find the *Zep System II Instructional Video*, *Engineering Certification Letter with Span Tables*, and link to the *Zepulator* online design tool.




### Zep Groove




Zep System II is installed with Zep Compatible PV modules whose frames have been manufactured with the **Zep Groove**.

### Zep Tool



The **Zep Tool** is used to install the Interlock, Leveling Foot, Hybrid Interlock, and Ground Zep. It also receives a T30 Torx bit for easy array leveling.

### Flat Tool



The **Flat Tool** is used to remove an Interlock between two modules for the purpose of module or Array Skirt removal.